



---

# HOW<sup>2</sup>

SPRAYING MANUAL



WEB & MIST/PEBBLE SPRAY

Quin Global UK  
Unit 1, Ruthvenfield Avenue  
Inveralmond Industrial Estate  
Perth, PH1 3WB

[www.quinglobal.com](http://www.quinglobal.com)  
[www.tensorglobal.com](http://www.tensorglobal.com)  
[sales.uk@quinglobal.com](mailto:sales.uk@quinglobal.com)  
0845 381 22 33

QUIN  
GLOBAL  
**Tensor**<sup>®</sup>

**Tensorgrip**<sup>®</sup>  
Adhesives That Outperform



---

# CONTENTS

Spray Patterns  
Setup  
Web Spray Application  
Mist/Pebble Spray Application  
Canister Changeover  
Disposal  
Substrates & Properties  
**HOW2** Tutorial Series  
Contact Us


## IDENTIFYING SPRAY PATTERNS

**\*\*IMPORTANT\*\*** ALWAYS CHECK WHAT TYPE OF SPRAY PATTERN YOUR ADHESIVE HAS BEFORE SPRAYING.



It is imperative that you identify the type of spray pattern that will be released from the canister; failure to identify this can lead to improper applications and undesired results. To confirm the product's spray pattern, simply check the label and a property icon (like the one pictured left and listed below) will indicate this.

## TYPES OF SPRAY PATTERN



### WEB SPRAY

The easiest visual comparison that can be made to a Web spray is that of a spider's web, hence the name!




### MIST SPRAY

Mist spray adhesives are released from the container as a fine mist, which creates a light and consistent droplet pattern on the surface it is sprayed upon.



### PEBBLE SPRAY

Pebble sprays are similar to Mist sprays however the pattern is made up of larger droplets, but still giving a smooth and consistent pattern on the surface.



### SNOWFLAKE SPRAY


Snowflake spray adhesives have a high build, large flake spray pattern which resemble snowflakes across the surface for single-sided bonds.

# SPRAY PATTTTERNS



## STEP 1.

Screw the larger hose nut to the gun thread (clockwise) and fully tighten with a spanner. Check hose is securely attached.



## STEP 2.

Screw the smaller hose nut to the canister valve (clockwise) and fully tighten with a spanner. Check the hose is securely attached.



## STEP 3.


Turn the canister valve anti-clockwise until fully open. Check connections for leaks - if any occur, tighten connections. **DO NOT TURN THE CANISTER VALVE OFF UNTIL THE CANISTER IS EMPTY** (this is to prevent adhesive curing in the hose and gun).



## STEP 4.

On initial use, or if canister has been standing for over 12 hrs, the hose and gun may require a purge. Pull the trigger and adjust flow by turning adjustment screw at the back of the gun (anticlockwise to open and clockwise to close). Dispense and discard adhesive until a consistent spray pattern is achieved.

# SETUP



# WEB SPRAY APPLICATION



## STEP 1.

Prepare the surface to be bonded; ensuring both faces are clean, free of dust, dirt and grease. If necessary wipe clean with proprietary solvent-based cleaner. **DO NOT USE WHITE SPIRIT, METHYLATED SPIRITS OR CITRUS-BASED CLEANERS.**




## STEP 2.

Hold spray gun at a constant distance of between 100-250mm (4" - 10") from the surface, allowing the adhesive to web across the surface with approximately 50-70% overlap to successive passes for thin laminates to reduce risk of telegraphing (note — correct coat weight must be achieved).



## STEP 3.


Maintain a constant speed of application during spraying, applying a consistent and thorough coating without allowing the adhesive to puddle or heavily 'wet' the surface. Maximum bond strength is achieved with coverage of between 80-100%, and a recommended minimum coat weight of 20 dry grams per m<sup>2</sup>.



## STEP 4.

Maximum adhesion will be obtained by spraying mating faces at 90° to each other, i.e. one face vertically, the other face horizontally. Double coating perimeter of face and edges is recommended, including areas around subsequent cutting positions.

- Do not angle spray gun or move in an arc while spraying. Hold gun at 90° to surface while spraying. Release trigger at end of each pass to optimize coverage.
- Many man-made boards such as plywood and especially flexi-ply and MDF are very absorbent and will need a primer coat (shown in 'COVERAGE TOO LIGHT' picture). Allow to dry, then apply the normal 'CORRECT APPLICATION', as shown, over top of primer coat.
- Many substrates should be regarded as difficult to bond, e.g. metal faced HPL, Colorcore etc. or products with memory (also soft and thick materials may require 2nd or 3rd coat). Best results are obtained by multiple coats rather than one heavy coat which may result in heavy wetting of surface and extended drying times. Always test before using in production – see disclaimer.
- Allow adhesive to dry (see product data sheets for appropriate drying times). Test for dryness using back of hand only; surface should be tacky but adhesive should not transfer to skin. Position substrates correctly and press together working from centre outwards. Apply adequate pressure using nip roller or 75mm hand roller and body weight as a minimum in order to achieve at least 35psi at glue line. Note; repositioning is not possible after contact has been made.
- Immediate trimming/routing is possible. Full strength is achieved after 24-48 hours depending on temperature and humidity.



COVERAGE TOO LIGHT



COVERAGE TOO HEAVY



CORRECT APPLICATION = 20 dry gms/m<sup>2</sup>



75mm HAND ROLLER



**WEB SPRAY  
APPLICATION**





## MIST/PEBBLE SPRAY APPLICATION





## STEP 1.

Prepare the surface to be bonded; ensuring both faces are clean, free of dust, dirt and grease. If necessary wipe clean with proprietary solvent-based cleaner. DO NOT USE WHITE SPIRIT, METHYLATED SPIRITS OR CITRUS-BASED CLEANERS.



## STEP 2.

Hold spray gun at a constant distance of between 200-400mm from the surface, allowing the adhesive to droplet across the surface with approximately 50-70% overlap to successive passes for thin laminates to reduce risk of telegraphing (note — correct coat weight must be achieved).



## STEP 3.


Maintain a constant speed of application during spraying, applying a consistent and thorough coating without allowing the adhesive to puddle or heavily 'wet' the surface. Maximum bond strength is achieved with coverage of between 80-100%, and a recommended minimum coat weight of 20 dry grams/m<sup>2</sup>.



## STEP 4.

Maximum adhesion will be obtained by spraying mating faces at 90° to each other, i.e. one face vertically, the other face horizontally. Double coating perimeter of face and edges is recommended, including areas around subsequent cutting positions.

- Do not angle spray gun or move in an arc while spraying. Hold gun at 45° to surface while spraying. Release trigger at end of each pass to optimize coverage.
- Many man-made boards such as plywood and especially flexi-ply and MDF are very absorbent and will need a primer coat (shown in 'COVERAGE TOO LIGHT' picture). Allow to dry, then apply the normal 'CORRECT APPLICATION', as shown, over top of primer coat.
- Many substrates should be regarded as difficult to bond, e.g. metal faced HPL, Colorcore etc. or products with memory (also soft and thick materials may require 2nd or 3rd coat). Best results are obtained by multiple coats rather than one heavy coat which may result in heavy wetting of surface and extended drying times. Always test before using in production – see disclaimer.
- Allow adhesive to dry (see product data sheets for appropriate drying times). Test for dryness using back of hand only; surface should be dry and adhesive should not transfer to skin. Position substrates correctly and press together working from centre outwards. Apply adequate pressure using nip roller or 75mm hand roller and body weight as a minimum in order to achieve at least 35psi at glue line. Note; repositioning is not possible after contact has been made.
- Immediate trimming/routing is possible. Full strength is achieved after 24-48 hours depending on temperature and humidity.



COVERAGE TOO LIGHT



COVERAGE TOO HEAVY




CORRECT APPLICATION = 20 dry gms/m<sup>2</sup>



75mm HAND ROLLER



**MIST/PEBBLE  
SPRAY APPLICATION**



**IMPORTANT:** SAFETY GLASSES AND GLOVES MUST BE PUT ON BEFORE STARTING THE DISPOSAL PROCESS


## STEP 1.

Turn the canister valve clockwise until fully closed. Pull the trigger on the gun and hold for 10 seconds to expel residual pressure.



## STEP 2.

Unscrew the hose nut and disconnect the hose from the empty canister (move to next page for canister disposal).



## STEP 3.

Connect the hose and gun to the new canister (go to Step 2 of **PREPARATION** and follow the process through to Step 4).

If you are not transferring the hose and gun to a new canister you will need to clean it to ensure it can be used again on future jobs.

# CANISTER CHANGEOVER

**IMPORTANT NOTE:** THIS PROCESS SHOULD BE FOLLOWED THROUGH IMMEDIATELY AND ADHESIVE SHOULD BE DISPENSED FROM THE NEW CAN OR THE GUN AND HOSE WILL BLOCK AND BECOME UNUSABLE.




## STEP 1.

Lay the empty canister on its side with the valve pointing AWAY from the operator, and well away from sources of ignition.

## STEP 2.

Open the canister valve (anti-clockwise) and release any residual pressure.



## STEP 3.

Stand canister upright. Use a hammer and brass punch or other non-sparking instrument to puncture the friable disc.

## STEP 4.

As long as the user is able to accept responsibility for de-pressurising the canister, it can be disposed of as per your normal scrap metal disposal (subject to local waste restrictions).

## TRANSPORT INFORMATION

- During transport, the recommended PPE (Refer to MSDS), First Aid Kit and suitable Fire Extinguisher should be readily accessible in the vehicle.
- Keep vehicle well ventilated at all times whilst it contains spray contact adhesive.
- Secure canister during transportation.



# DISPOSAL



## SUBSTRATE IDENTIFICATION ICONS



## PRODUCT PROPERTY ICONS



Our series of SUBSTRATE and PROPERTY icons have been designed to make identifying our products as simple as possible.

# SUBSTRATES & PROPERTIES

# HOW2

## TUTORIAL SERIES

WATCH OUR ADHESIVE EXPERTS  
GIVE STEP-BY-STEP ADVICE ON  
BONDING WITH **TENSORGRIP®** IN  
OUR ONLINE TUTORIAL SERIES!

SCAN  
HERE



---

# CONTACT US

If you are having trouble with one of our products or if you require any further information, please don't hesitate to get in touch.

## Quin Global UK

Unit 1, Ruthvenfield Avenue  
Inveralmond Industrial Estate  
Perth, PH1 3WB

## Call:

+44 845 381 22 33

## E-mail:

[technical.uk@quinglobal.com](mailto:technical.uk@quinglobal.com)

## Visit:

[www.tensorglobal.com](http://www.tensorglobal.com)  
[www.quinglobal.com](http://www.quinglobal.com)

Got an application or unique project that you plan to use our products on?

**Show us on Twitter!**

Tweet us a photo of your work followed by:

# #UNLEASHTENSOR



CONNECT WITH US ANY TIME, ANYWHERE!

Copyright © 2016 by Quin Global UK Ltd

All rights reserved. This publication or any portion thereof may not be reproduced or used in any manner whatsoever without the express written permission of the publisher.

Printed in the UK

## GUARANTEE

Before using the product, the user should carry out any necessary tests in order to ensure that the product is suitable for the intended application. Moreover, all users should contact the seller or the manufacturer of the product for additional technical information concerning its use if they think that the information in their possession needs to be clarified in any way, whether for normal use or a specific application of our product. Our guarantee applies within the context of the statutory regulations and provisions in force, current professional standards and in accordance with the stipulations set out in our general sales conditions. The information detailed in the present technical data sheet is given by way of indication and is not exhaustive. The same applies to any information provided verbally by telephone to any prospective or existing customer.